


AR77.20-P-1150PB

Removing and installing rubber bellows on sliding/pop-up roof

12.1.01

MODEL 203.7

- 1 Rubber bellows mount
- 2 Rubber bellows
- 3 Guide rail
- 4 Rubber bellows rail
- 5 Sliding/pop-up roof cover
- 6 Guide pin



P77.50-2038-06

	Removing, installing		
Danger!	Risk of injury to fingers being jammed or squeezed when removing and installing or aligning hoods, doors, trunk lid/tailgate and sliding roof.	When moving components ensure that no body parts or limbs are in the area of movement.	AS00.00-Z-0011-01A
1	Open sliding/pop-up roof		
2	Unclip front rubber bellows mount (1)		

3	Pivot rubber bellows mount (1) upward		
4	Unclip rubber bellows mount (1) at rear and remove		
5	Unclip rubber bellows (2) from guide rail (3)	 Start at rear	
6	Pull rubber bellows (2) out of rubber bellows rail (4)		
7	Remove rubber bellows (2)	 Angularly toward front.	
8	Move sliding/pop-up roof to pop-up position		
9	Unclip rubber bellows rail (4)	 Start at rear	
10	Pull rubber bellows rail (4) out of sliding/pop-up roof cover (5)	 Installation: Guide pin (6) should catch audibly.  Toward front.	
11	Install in the reverse order		