


AR77.20-P-1550PB	Removing and installing cover carrier	12.1.01
------------------	---------------------------------------	---------

MODEL 203.7

- 1 Screws
- 2 End stop
- 3 Cover carrier



P77.20-2185-06

	<p>Removing, installing</p>		
1	Remove sliding/pop-up roof cover		<p>AR77.20-P-1000PB</p>
2	Move pop-up mechanism toward rear	<p> Ensure that cover carrier (3) is positioned properly on left and right.</p> <p> Until end stop (2) is freely accessible.</p>	

3	Unscrew screws (1)		
4	Remove end stop (2)		
5	Move pop-up mechanism toward front	 Ensure that cover carrier (3) is properly positioned on left and right.  Until cover carrier (3) can be removed.	
6	Remove cover carrier (3)	 Pivot out toward side	
7	Install in the reverse order		