



AR82.20-P-1000P	Removing and installing overhead control panel control module	23.10.99
-----------------	---	----------

**MODEL 203***Illustrated on model 203.0*

1 Lens  
 2 Release  
 N70 Overhead control panel control module



P82.20-2342-06

**Modification notes**

25.1.01	Entry pattern changed	P82.20-2238-05	
	Prying out rear overhead control panel control module (N70) modified	Step 2	
	Swinging down overhead control panel control module (N70) modified	Step 3	

	<b>Removing, installing</b>		
 <b>Danger!</b>	<b>Risk of explosion</b> from gas. <b>Risk of poisoning and caustic burns</b> from swallowing battery electrolyte. <b>Injury hazard</b> and danger of burning skin and eyes when handling battery acid or handling damaged lead-acid batteries	No fire, sparks, naked flames or smoking. Wear acid protection gloves, clothes and goggles. Pour battery electrolyte only into suitable and appropriately marked containers.	<a href="#">AS54.10-Z-0001-01A</a>
1	Disconnect ground cable of battery		<a href="#">AR54.10-P-0003P</a>
	Notes on battery	All models	<a href="#">AH54.10-P-0001-01A</a>
2	Pry lens (1) off of overhead control panel control module (N70)	 Danger of breaking headliner and overhead control panel control module (N70)	
		 Assembly wedge	<a href="#">110 589 03 59 00</a>
3	Actuate releases (2) of overhead control panel control module (N70)	 Observe direction of arrow.	
4	Remove overhead control panel control module (N70)	 From front guide.	
5	Disconnect connectors from overhead control panel control module (N70)		
6	Install in the reverse order		
7	Connect STAR DIAGNOSIS, read out DTC memory		
 <b>AD</b>			<a href="#">AD00.00-P-2000-04A</a>



110 589 03 59 00

Assembly wedge