


AR77.20-P-2400PB

Removing and installing coupling arm for wind deflector


12.1.01

MODEL 203.7

- 1 Bolt
- 2 Wind deflector
- 3 Coupling arm
- 4 Screw
- 5 Lock washer



P77.20-2179-01



P77.25-2004-01

	Removing		
1	Move sliding/pop-up roof toward rear		
2	Unscrew screw (4) from coupling arm (3)		
3	Remove lock washer (5)		
4	Remove bolt (1)		
5	Move coupling arm (3) toward front		
6	Loosen coupling arm (3) from wind deflector (2) and remove		
	Installation		
7	Align coupling arm (3) on wind deflector (2)		
8	Install bolt (2)	Bolt should not have perceptible play. From inside to outside	

9	Install lock washer (5)		
10	Hook in coupling arm (3)		
11	Screw screw into coupling arm (3)		
12	Close sliding/pop-up roof		