

AR88.85-P-2100P	Removing and installing water deflector	11.1.00
-----------------	---	---------

MODEL 203.0


MODEL 203.7 except CODE (413) Panorama sliding roof

Illustrated on model 203.0

2 Clips

3 Clips


4 Windshield




P88.85-2040-02



P88.85-2041-02



P88.85-2042-01




P88.85-2043-01




P88.85-2044-01

1 Water deflector


3 Clips



P88.85-2045-01



P88.85-2046-01




P88.85-2047-01


Illustrated on Model 203.0
 1 Water deflector

3 Clips

5 Rear window

	Remove		
1	Pull out water deflector (1)	First out of clip (2) on A-pillar, then out of clip (3) in area of roof.	
2	Remove water deflector (1)	Check water deflector (1) and replace according to condition.	
3	Remove clips (3)	Mark position of clips (3).	
	Install		
4	Install new clips (3) in roof gutter		
5	Fit water deflector (1) in place and align	Impacts to water deflector (1) to be made in clip (2,3) area only. Start at the rear window (5) and knock into the clips (2,3) by hand. The water deflector (1) should make contact with the roof edge.	
6	Install water deflector (1) with installation wedge by tapping lightly with rubber hammer	Glue felt strip onto long wedge. Impacts to water deflector (1) to be made in clip (2,3) area only.	

	 Long wedge	115 589 03 59 00
--	--	----------------------------------



115 589 03 59 00

Long wedge