



AR77.20-P-2500PB	Remove/install wind deflector	22.8.00
------------------	-------------------------------	---------

MODEL 203.7

- 1 Pin
- 2 Wind deflector
- 3 Coupling arm
- 4 Bolt
- 5 Seal lip
- 6 Bolts



P77.20-2180-01



P77.20-2179-01

	Remove		
1	Move tilting/sliding roof toward rear		
2	Unscrew bolt (4) from coupling arm (3)	 Do not remove bolt (1). Left and right side.	
3	Unscrew bolts (6) out of front bearing	 Left and right side	
4	Move coupling arm (3) toward front	 Left and right side	
5	Remove wind deflector (2) toward rear	 Do not damage seal lip (5).	
	Install		
6	Move in wind deflector (2) at front	 Do not damage seal lip (5).	
7	Hook in coupling arm (3)	 Left and right side	
8	Turn in bolts (6) at front bearing	 Do not tighten completely. Left and right side.	
9	Screw bolt (4) into coupling arm (3)		

		i Left and right side	
10	Move wind deflector (2) upward and downward with hand	i Until wind deflector (2) is centered	
11	Close tilting/sliding roof		
12	Check position of wind deflector (2) and correct, if necessary	i Wind deflector (2) should be flush with tilting/sliding roof cover at front and on side.	
13	Open tilting/sliding roof		
14	Tighten bolts (6) on front bearing		
15	Close tilting/sliding roof		
16	Check wind deflector (2) position again and correct if necessary		
17	Perform teach-in procedure for sliding roof obstruction sensor		AD00.00-P-2000-04A
		Diagnosis system STAR DIAGNOSIS	WE58.40-Z-1013-06A

Workshop equipment/MB testers (see Workshop Equipment Manual)

WE58.40-Z-1013-06A	STAR DIAGNOSIS Compact diagnosis system for passenger cars, order number 6511 1801 00
--------------------	---